

# Pressure Gauge for General Purpose (DT type)

## Series G43

RoHS



G43-10-01

- Be sure to read the precautions on page 739 for selection and mounting.

### Standard Specifications

Model		G43
Type		Back side thread
Port size <sup>(1)</sup>		R 1/8, R 1/4
Fluid <sup>(2)</sup>		Air
Indication precision		±3% F.S. (Full span)
Material	Case	Stainless steel
	Clear cover	Glass
	Stud	Brass
	Bourdon tube	Brass
Applicable model		IP200, IP8000, IR2000, IR3000, IT2000, 4000

Note 1) When mounting a pressure gauge, use caution not to tighten excessively. Excessive tightening will cause product to be damaged. Use a pipe tape for sealing. Recommended tightening torque: R 1/8: Set between 7 to 9 N·m, R 1/4: 12 to 14 N·m respectively.

Note 2) When using with water, use G43-□-X3 (wetted parts stainless steel) and use caution not to apply water hammer. When using the other fluids, please consult with SMC for fluid compatibility information concerning corrosive potential.

### Model (Standard)

Model	Pressure range <sup>(1)</sup> MPa	Indication unit	Connection thread	Note
G43-2-01 to 02	0 to 0.2	MPa	R 1/8, R 1/4	—
G43-4-01 to 02	0 to 0.4		R 1/8	
G43-6-01	0 to 0.6		R 1/8	
G43-7-01 to 02	0 to 0.7		R 1/8, R 1/4	
G43-10-01 to 02	0 to 1.0			

Note 1) Do not apply pressure more than the maximum display pressure. This will cause a malfunction.

### Model (Made to Order)

Model	Pressure range <sup>(1)</sup> MPa	Indication unit	Connection thread	Note
G43-2-01 to 02-X2	0 to 0.2	MPa	R 1/8, R 1/4	X2: Stud parts nickle plated
G43-4-01 to 02-X2	0 to 0.4		R 1/8	
G43-6-01-X2	0 to 0.6		R 1/8, R 1/4	
G43-7-01 to 02-X2	0 to 0.7		R 1/8, R 1/4	
G43-10-01 to 02-X2	0 to 1.0			X3: Wetted parts stainless steel
G43-2-01 to 02-X3	0 to 0.2		R 1/8, R 1/4	
G43-4-01 to 02-X3	0 to 0.4		R 1/8	
G43-6-01-X3	0 to 0.6		R 1/8, R 1/4	
G43-7-01 to 02-X3	0 to 0.7		R 1/8, R 1/4	
G43-10-01 to 02-X3	0 to 1.0			X4: Oil-free (Wetted parts degreasing)
G43-2-01 to 02-X4	0 to 0.2		R 1/8, R 1/4	
G43-4-01 to 02-X4	0 to 0.4		R 1/8	
G43-6-01-X4	0 to 0.6		R 1/8, R 1/4	
G43-7-01 to 02-X4	0 to 0.7			
G43-10-01 to 02-X4	0 to 1.0			

Note 1) Do not apply pressure more than the maximum display pressure. This will cause a malfunction.

## How to Order

**G 43** - **10** - **01** -  

Pressure gauge •      ①      ②      ③

		Symbol	Description	G43
①	Max. display pressure	+		
		2	0.2 MPa	●
		3	0.3 MPa	●
		4	0.4 MPa	●
		6	0.6 MPa	●
		7	0.7 MPa	●
		10	1.0 MPa	●
		P2 <sup>(1)</sup>	0.2 MPa, 30 psi	○ <sup>(2)</sup>
		P4 <sup>(1)</sup>	0.4 MPa, 60 psi	○ <sup>(2)</sup>
		P6 <sup>(1)</sup>	0.6 MPa, 90 psi	○ <sup>(2)</sup>
P7 <sup>(1)</sup>	0.7 MPa, 100 psi	○ <sup>(2)</sup>		
P10 <sup>(1)</sup>	1.0 MPa, 150 psi	○ <sup>(2)</sup>		
②	Connection thread	+		
		01	R 1/8	●
		02	R 1/4	●
③	Special specification	+		
		Nil	—	●
		X2	Stud parts nickel plated	—
		X3 <sup>(3)</sup>	Wetted parts stainless steel	●
		X4	Oil-free (Wetted parts degrease washing)	●
		X30	Both MPa and psi	○ <sup>(2)</sup>

Note 1) This symbol must be used with Special specification "X30."


Note 2) Under the New Measurement Law, products for overseas use only (SI unit type for use in Japan)

Note 3) Movable parts (gear, etc.) inside pressure gauge are made of brass.

Note 4) Cover ring assembly is not available.

## Dimensions (Except Made-to-Order products)

G43-□-01 to 02



\* The dimensions in ( ): Connection thread R 1/4

G

GS

PPA